

Duux®

user guide!

Duux baby projector

[congratulations!]

Congratulations on the purchase of your Duux product! To use our online service, please register your product and warranty on www.duux.com/register

Duux develops reliable baby electronics with a beautiful design and maximum ease of use to make life a lot easier for parents with newborns so that they can enjoy this special time. The Duux Baby Projector will help your baby fall asleep easily with a sky full of stars and soothing lullabies. What if your baby suddenly starts crying at night? Don't worry, the built in voice activation makes sure that the projector starts beaming again to ensure yours and your baby's rest. Read this manual carefully to get the most out of your baby projector.

[table of contents]

1	Product overview	4	3	Installation & Use	10
	Box contents	4	4	Functions	11
	Baby projector	4	5	Maintenance	13
	Technical specifications	7	6	Warranty & Service	14
2	Important!	8	7	FAQ	16
	General	8			
	Installation	9			
	Use	9			
	Environment	9			

1 product overview

The box contains the following parts:


- | | |
|-------------------------------|------|
| 1. Baby projector base | (1x) |
| 2. Baby projector cap 'stars' | (1x) |
| 3. Power adapter | (1x) |
| 4. User guide | (1x) |



[3]



[4]



[technical specifications]



- ▶ Operating temperature range: 10-40 °C
- ▶ Storage temperature range: 10-40 °C
- ▶ Power consumption: <1W
- ▶ Number of Cold LED's: 3
- ▶ Adapter input: AC 100-240V 50/60Hz 0.2A
- ▶ Adapter output 5.0V 1A
- ▶ Box dimensions: 190 x 190 x 190 mm (W x H x D)
- ▶ 1 year warranty

2 important!

Read these instructions carefully before using the device. Please keep this user guide for future reference.

General

- ▶ The baby projector may only be used in accordance with these instructions.
- ▶ The baby projector is designed to help. It is not a substitute for proper supervision by adults and should not be used as such.
- ▶ Use only the supplied adapters
- ▶ Do not immerse any part of the baby projector in water or other liquids.
- ▶ Do not use the baby projector in a humid environment or near water.
- ▶ Use and store the device at a temperature between 10°C and 40°C.
- ▶ While powered on, keep the device out of the reach of children and persons who may not be able to safely operate the baby projector.
- ▶ Ensure a good outflow of heat. Do not cover the baby projector and never use it next to a heat source. Do not expose to direct sunlight.
- ▶ Make sure the adapter cord does not get damaged and avoid tripping or falling over this cord.
- ▶ Repairs may only be performed by a qualified electrician. Do not try to repair the device yourself. Always return to the point of sale in the event of defects or damage.
- ▶ Only use accessories that are recommended by the supplier. Use of other accessories may cause damage to the baby monitor and pose a risk to the user.
- ▶ Supervise children to prevent them from playing with the appliance.

Installation

- ▶ Do not install the baby projector during a thunderstorm.
- ▶ Only connect or disconnect the adapter to the baby projector when removed from the AC power supply.
- ▶ Only use the provided adapters listed in this user guide. Check if the voltage indicated on the adapters and chargers matches the local voltage before connecting to the baby projector.

Use

- ▶ Test the baby projector before use. Become familiar with its functions and features.
- ▶ Do not place the baby projector in the bed or playpen.
- ▶ Only use the baby monitor in an upright position.
- ▶ Never open the casing of the baby projector to prevent electric shocks. Opening the casing will invalidate the warranty.
- ▶ Always remove the plug from the cord when the baby projector is not being used.

Environment

- ▶ The outer packaging of this baby projector can be returned as waste paper. However, we recommend keeping all packaging, so that the unit can be transported safely, in the appropriate packaging.

3 installation & use

Note: make sure that the baby projector is on a flat and stable surface to prevent falling.

Note: make sure that the baby projector is within 2 metres reach of the walls/ceiling in order to have clear projections.

1. Put the power adapter in the power socket
2. Put the adapter into the baby projector (back side)
3. Switch on the baby projector by pressing the on/off button

Note: always switch off the baby projector first before disconnecting the adapter.

The baby projector has a built-in voice activation function that automatically activates the projector when the baby starts crying (at night). After activation, the projector will automatically turn off again after 30 minutes.

4 functions



1. Press this button once to switch on the baby projector.
2. Press this button again to also activate the nightlight.
3. Press this button again to switch off the baby projector.



Use this button to change the projecting animation.

1. Press this button once to only project a solid blue color.
2. Press this button once to only project a solid red color.
3. Press this button once to only project a solid green color.
4. Press this button again to switch off the projecting function.

Note: what if you only want to use the nightlight without projecting? Press the power icon twice to activate the projector and the nightlight. Then press the lightbulb icon 4 times to switch off the projecting function.

Note: the nightlight and projector functions will automatically stop after 30 minutes (your child should be asleep by then...)



1. Press this button once to play lullaby 1
2. Press this button again to play lullaby 2
3. Press this button again to play lullaby 3
4. Press this button again to play all lullabies.
5. Press this button again to stop playing lullabies.

Cleaning

Disconnect the adapter before cleaning.

Only clean the baby projector and adapter with a dry cloth, do not use chemical cleaners.

Make sure the cleaned baby projector is dry before connecting to the power supply.

Spare parts

Spare parts and accessories can be requested at the point of purchase.

6 warranty & service

Register your warranty on www.duux.com/register

The Duux baby projector has a warranty of 12 months after the date of purchase. During this period we guarantee the repair of defects caused by material and manufacturing defects. This must be assessed by the distributor in the country concerned.

In the event of a defect please first consult your user manual and the online FAQ (frequently updated on www.duux.com) at all times. If no solution is offered, you are requested to contact your supplier. If the supplier is unable to repair the defect, they will contact Duux customerservice.

Warranty period

- ▶ The warranty period will not be extended, even in the event of repairs being made.
- ▶ The warranty provides a right to have a product repaired but not to exchange or return a product.
- ▶ Duux's obligation under this warranty is limited to the repair or replacement of defective parts as deemed necessary and as covered under this warranty.
- ▶ Duux reserves the right to improve the design of any product without assuming any obligation to modify the previously manufactured products.
- ▶ The warranty may only be invoked if you provide Duux with the original purchase receipt along with the defective product. Your warranty registration must be on file when warranty service is required.

No warranty will be provided in the following circumstances:

- ▶ If you have made or arranged for modifications or repairs to be made without written permission first having been received from Duux or the retailer.
- ▶ Normal wear and tear or damage due to accident, carelessness, lack of maintenance, misapplication, improper use or use of accessories and parts which are not manufactured by Duux, as well as altered and/or disassembled components.
- ▶ Defects resulting from any use or maintenance other than that indicated in the user guide.

Important:

- ▶ This warranty period commences upon purchase of the product and is validated by registering online at www.duux.com.
- ▶ In the event of any dispute regarding product warranty, Duux reserves the right to take all final decisions on warranty.


7 FAQ

The Duux baby projector has a warranty of 12 months after the date of purchase. During This section lists the questions most frequently asked about the appliance. We will frequently update this FAQ online with the latest issues, so please keep an eye on our website www.duux.com!

How come I see blurry projections on the ceiling and walls?

Please put your projector on a higher surface to cover the projecting distance (max. 1.8 metres). The farther away you put the projector, the blurrier the images get.

Can I turn off the voice activation?

Yes, you can turn off the voice activation function. Just switch on the baby projector with the  icon and the projector will work for 30 minutes without re-activating.

Can I also play lullabies with voice activation?

No, you can only use projections with voice activation (pre-set). If the voice activation accidentally activates at night, the child will not wake up from the projecting, but could wake up from the lullabies.

Do you offer any other projection caps, in addition to the stars?

Yes, we do offer other caps. Please ask your local retailer.



Duux baby projector

Manufactured, distributed or sold by Duux Europe BV, owner of DUUX and the DUUX logo and other DUUX trademarks. DUUX and the DUUX logo are registered trademarks. All other product or service names are the property of their respective owners.

©Duux International BV 2012. All rights reserved.

Version 1.0



Printed in P.R.C.

The features & specifications described in this user guide are subject to change without prior notice.